Frigidaire

Factory Parts Catalog

Product No.	FGB24T3ECD
	38454413B50S4
Series	24" double gas
Color	stainless
Market	North America
Wiring Diagram	318046309
Owner's Guide	318200958
Installation Instructions	318201554
Timer Guide	318200144

Electrolux

Electrolux Major Appliances
North & Latin America
P.O. BOX 212378
AUGUSTA, GA 30917

Publication No.
5995491437
07/05/24
(EN/SERVICE/BJH)
377

DOUBLE GAS WALL OVEN

Model No.
FGB24T3E

Copyright © 2007 Electrolux Home Products, Inc.
All rights reserved.

CONTROL PANEL



CONTROL PANEL

POS. NO	PART NO.	DESCRIPTION
16	318116906	Plate, instrument mtg
19	318212505	Glass, control panel, black
20 #	316455461	Clock/Timer, electronic, ES100
*	08016432	Screw, truss head, 8-18 x 0.375
24 #	316090900	Switch, oven light, black
28	5304410865	Tube, timer knob
29	318017711	Knob, clock/timer, black
64	318110700	Bracket, light switch
*	5303211311	Screw, 8 x 0.500

BURNER



BURNER

POS. NO	PART NO.	DESCRIPTION
14 #	5303210167	Regulator, pressure
17 #	5303210156	Valve, safety
18 #	5303207603	Burner, oven
20	5303317122	Baffle, oven burner
21	3201885	Nut, Keps, 10-24
26 #	318177710	Ignitor, oven burner
28 #	5303295305	Valve, shut off
49	5303317124	Bracket, safety valve
59	5303317123	Bracket, safety valve, support
64	5303295303	Retainer, oven burner
*	5303211311	Screw, 8 x 0.500
*	5303311333	Screw, 8-32 x 3/8
*	5303323135	Screw, 10 x 1-7/8

BODY


56
97
249
121
251
58D
124
3
130
248
242
58A
250
98
36
83
158
158A
37
250
158A
158
14
15
244
247
216
247
10
85
85D
136
33
244A
130
3
7
9
85A
136
6
7A
8
85B
85C
29
98A
246
29
6
39
216A
25
103
BFGB24T3ESC

BODY

POS. NO	PART NO.	DESCRIPTION
3	5303317132	Wrapper, side, outer
6	318345800	Rack, oven, upper & lower, (3)
7	5303298313	Hinge Assy, RH lower
7A	5303298312	Hinge Assy, LH lower
8	318136500	Panel, oven bottom
9	5303317977	Pan, broiler
10	5303317976	Insert, broiler pan
14	318224000	Receptacle, oven light
15	5303013071	Bulb/Lamp, light
25	5303317712	Shield, heat, lower
29	5303209887	Glide, broiler rack
33	5303317128	Shield, heat
36	5303298341	Flue
37 #	316217005	Probe, oven temp
39	318144008	Cord, service
56	318028200	Trim, oven top
58A	318285007	Insulation, oven back
58D	318285008	Insulation, oven wrapper
83	318109511	Liner, oven assy
85	5303317711	Spring, oven door, lower
85A	318113300	Bracket, door spring, lower
85B	5303317126	Bracket, door spring, upper
85C	5303207651	Spring, oven door, (1)
85D	318166900	Sleeve, door spring
97	5303317130	Wrapper, top, outer
98	318029001	Trim, bodyside, black, RH
98A	318029000	Trim, bodyside, black, LH
103	5303316735	Trim, base, black, lower
121	5303317131	Wrapper, back
124	318076801	Box, horizontal flue
130	318034600	Cap, end top, black, (2)
136	5303317129	Angle, rack guide
158	5303207644	Seal, door, black, top broiler
158A	5303295311	Seal, side, bake oven
216	318034500	Cap, end bottom, black, RH
216A	318034501	Cap, end bottom, black, LH
242	318027200	Trim, center, black
244	5303205940	Hinge Assy, oven door, RH upper
244A	5303205939	Hinge Assy, oven door, LH upper
246	318133600	Panel, oven bottom
247	3018717	Glide, oven rack
248	5303317121	Cap, flue
249	5304400385	Wrapper, top, inner
250	318285042	Insulation, 3" X 2" X 17.5", (2)
251	318285048	Insulation, 2"X 2.5"X 21.5"
*	318232522	Wiring Harness, main
*	5304400429	Screw (8-18 X 1)
*	5303211311	Screw, 8 x 0.500
*	5303300265	Screw, 8-18 X 1/2, (2)
*	5303311333	Screw, 8-32 x 3/8

DOOR



DOOR

POS. NO	PART NO.	DESCRIPTION
4	318178504	Glass, door, black, outer
6	318116600	Shield, wool
7	318285009	Insulation, oven door
9	318048901	Liner, oven door
10	5304416408	Screw, 10-24 x 1.750, handle mtg
13	318328400	Panel, exterior door, stainless
16	318042310	Glass, door, heat barrier
17	5304400397	Fastener, spacer
20	5303300175	Spacer, handle, black
29	318014401	Spacer, door
39	318186101	Handle, door, black
54	5303308456	Screw, 8-18 x 0.531, black
62	08010463	Fastener, clip
*	08016432	Screw, truss head, 8-18 x 0.375
*	5303211311	Screw, 8 x 0.500
*	5303311333	Screw, 8-32 x 3/8

WIRING DIAGRAM